



- Input for potentiometers
- Analog output
- Up to 7 200 measurements/s
- Quick configuration by DIP switch
- PC configurable via USB port
- Galvanic isolation 2.5 kVAC
- Simple installation to DIN rail

# OMX 380iDU

## Digital DIN rail mounted signal convertor

### INPUT FOR POTENTIOMETERS



### LED Indication

Hi	Lo	Status
●		Device is running
✱		Device functionality is limited, powered via USB
✱		This device has a Delayed Start option
●		Error: device is out of order
●	○	Tare function is activated
●	●	Error: of input (> ±110% of range) or of sensor [ERR.1, 3]
●	●	Error: AO loop open [ERR.10]
●	●	Error: setting/ calibration [ERR.34-36]
✱	✱	Serious error (Safe mode) [ERR.50]
✱	✱	Button function is blocked
●	●	Simulation mode is activated

### Legend

- ① Connectors
- ② Control button
- ③ RGB Status LED
- ④ microUSB port for PC connection

**⚠ DANGER ⚠**

**HAZARD OF ELECTRICAL SHOCK**

- Disconnect all power and other supply lines before servicing equipment

Failure to follow this instruction may result in death or serious injury.


**⚠ WARNING ⚠**

**EQUIPMENT OPERATION HAZARD**

- Do not use this product in safety critical system
- Do not disassemble, repair or modify this product
- Do not operate beyond the recommended operating environment

Failure to follow these instructions may result in death, serious injury, or equipment damage.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by ORBIT MERRET for any consequences arising out of the use of this device.




**Note**

Contactors, high power electric motors, frequency drives and other power devices should not be in a close proximity of the meter. Input signal leads (measured value) should be separated from all power lines and power devices. Even though the device has been designed and tested according to standards for industrial environment, we strongly advise to adhere to the above presented rules.


	0,05...2,5mm <sup>2</sup> 30...12 AWG	
	Ø 3,5 mm Ø 0.14 in	1,5 Nm 13.2 lb-in

## Input wiring diagram

Input - Potentiometers




Input - External inputs




Control of external inputs is via contact (voltage-free)

## Output wiring diagram

Analog current output [mA]



Analog Voltage Output [V]



Analog output	
0...5/20 mA	3 - 4
4...20 mA	
0...2/5/10 V	3 - 5
±10 V	

## 3

## Device setting

### DIP switch

For a quick set up you can use the DIP switch

1 2	Input
	Setting via OM Link
●	Potentiometer (default)

3 4 5	Rate [measurements/s]
	50
●	300
●	400
●●	400 - FFT
●	1200
●	2400
●●	4800
●●●	7200 (default)

6 7 8	Output - range
	0...2 V
●	0...5 V
●	0...10 V
●●	±10 V
●	0...5 mA
●	0...20 mA
●●	4...20 mA (default)
●●●	Er 4...20 mA

### Analog input range setting, TEACH-IN

- by a short press of the **Lo** button enter the configuration mode - LED **Hi** ✨ yellow and LED **Lo** ● turquoise
- connect the signal of the desired value for the minimum of the range **RNG.MIN** (for example 5 mA)
- by a long press (>2s) of the **Lo** button this value is set - LED **Hi** ✨ yellow, LED **Lo** ● purple
- connect the signal of the desired value for the maximum of the range **RNG.MAX**. (for example 19,5 mA)
- by a long press (>2s) of the **Lo** button this value is set - LED **Hi** ✨ yellow, LED **Lo** ● green
- by a short press of the **Lo** button return to the standard working mode - LED **Hi** ● green



Setting of **Analogue input TEACH-IN** is active only when DIP switches No. 1-2 are in the "0" position, i.e. **Setting via OM Link**

### Tare settings

- by a short press of the **Hi** button enter configuration of Tare - LED **Hi** ☼ white and LED **Lo** ● turquoise
- by a long press (>2s) of the **Hi** button set the current value of Tare - LED **Hi** ☼ white, LED **Lo** ● green
- by a short press of the **Hi** button return to the standard working mode with active Tare - LED **Hi** ● green, LED **Lo** ○ white



Minimum range of **Analog output** for U/I inputs signals is pre-set as unipolar, i.e. "0 V/mA" or "4 mA". If required, it is also possible to enter a negative value of the maximum in the minimum, i.e. zero will be in the middle of the selected range.



A short press at any time during the calibration will end the calibration without saving. After one minute of inactivity, the calibration is terminated without saving and both LEDs return to the basic state

# 4 Configuration from PC using OM Link SW

## Inputs

Reset of Tare	CLEAR	>	<input type="button" value="CL.TAR."/>	Tare resetting	
Sampling rate	READ. S.	>	<input type="button" value="50"/> <input type="button" value="100"/> <input type="button" value="400"/> <input type="button" value="1200"/> <input type="button" value="2400"/> <input type="button" value="4800"/> <input type="button" value="7200"/>	Measuring rate selection	
Measuring range	M.RANGE	>	<input type="button" value="0-100%"/>	Measuring range selection	
Preset tare	P. TARE	>	<input type="button" value="0...9999"/>	Setting of fixed tare	
Setting of converted value	RNG.MIN.	>	<input type="button" value="-99999...0...999999"/>	For the minimum of the selected input range	<input type="button" value="T-IN.LO"/> Device measures the value of the Lo signal <input type="button" value="ANO"/> Lo signal connection confirmed <input type="button" value="T-IN.HI"/> Device measures the value of the Hi signal <input type="button" value="ANO"/> Hi signal connection confirmed <input type="button" value="MAN.LO"/> Manual entry of Lo input signal for MIN <input type="button" value="4.02"/> Entry of signal value (example: 4.02 Ω) <input type="button" value="MAN.HI"/> Manual entry of Hi input signal for MAX <input type="button" value="997.2"/> Entry of signal value (example: 997.2 Ω)
	RNG.MAX.	>	<input type="button" value="-99999...100...999999"/>	For the maximum of the selected input range	
Input setting Expert	TEACH-IN	>	<input type="button" value="T-IN.LO"/> <input type="button" value="T-IN.HI"/>	Setting the input range in the Teach-in mode	
	MANUAL	>	<input type="button" value="MAN.LO"/> <input type="button" value="MAN.HI"/>	Setting the input range in the Manual mode	
Digital filters	F.MODE	>	<input type="button" value="OFF"/> <input type="button" value="AVERAG."/> <input type="button" value="FL.AVG."/> <input type="button" value="EXPON."/> <input type="button" value="ROUND."/>	Filters for math. adjust. of the input signal	
Filter constant	F.CONST.	>	<input type="button" value="0...9999"/>	Setting the constant for the filter	
External input	EXT.IN.1	>	<input type="button" value="OFF"/> <input type="button" value="TARE"/> <input type="button" value="CL.TAR."/> <input type="button" value="HOLD"/> <input type="button" value="SAMPLE"/> <input type="button" value="HLD.MIN"/> <input type="button" value="HLD.MAX"/> <input type="button" value="HLD.MM"/> <input type="button" value="KEY.LCK."/>	Selection of functions controlled by external input 1	
	EXT.IN.2	>	<input type="button" value="OFF"/> <input type="button" value="TARE"/> <input type="button" value="CL.TAR."/> <input type="button" value="HOLD"/> <input type="button" value="SAMPLE"/> <input type="button" value="HLD.MIN"/> <input type="button" value="HLD.MAX"/> <input type="button" value="HLD.MM"/> <input type="button" value="KEY.LCK."/>	Selection of functions controlled by external input 2	

## Function

Mathematical function	INP. M.F.	>	<input type="button" value="OFF"/> <input type="button" value="INPUT"/> <input type="button" value="FILTER."/>	Input selection for the math function	<input type="button" value="POLYN."/> Polynomial $Ax^4 + Bx^3 + Cx^2 + Dx^2 + Ex + F$ <input type="button" value="IN.POL."/> Inv. polynomial $\frac{A}{x^2} + \frac{B}{x^2} + \frac{C}{x^2} + \frac{D}{x^2} + \frac{E}{x} + F$ <input type="button" value="LOGAR."/> Logarithmic $A \cdot \ln\left(\frac{Bx+C}{Dx+E}\right) + F$ <input type="button" value="EXPON."/> Exponential $A \times e^{\left(\frac{Bx+C}{Dx+E}\right)} + F$ <input type="button" value="POWER"/> Power $A \times (Bx + C)^{(Dx+E)} + F$ <input type="button" value="SQ.ROOT"/> Square root $A \times \sqrt{\frac{Bx+C}{Dx+E}} + F$
	TYPE.M.F.	>	<input type="button" value="POLYN."/> <input type="button" value="IN.POL."/> <input type="button" value="LOGAR."/> <input type="button" value="EXPON."/> <input type="button" value="POWER"/> <input type="button" value="SQ.ROOT"/>		
	CONST. A ... F	>	<input type="button" value="0...99"/>	Setting constants for mathematical functions	
Linearization table	INP. LT.	>	<input type="button" value="OFF"/> <input type="button" value="INPUT"/> <input type="button" value="FILTER."/>	Input selection for the linearization table	
	N.OF.PTS.	>	<input type="button" value="5...100"/>	Number of points in the table	
	VALUES	>	<input type="button" value="-9999...99999"/>	Values of X/Y	

## Output

Analog output	INP. A.O.	>	<input type="button" value="INPUT"/> <input type="button" value="FILTER."/> <input type="button" value="MAT.FNC."/> <input type="button" value="LIN.TAB."/>	Selection of input for analogue output	
	A.O.TYPE	>	<input type="button" value="0-2 V"/> <input type="button" value="0-5 V"/> <input type="button" value="0-10 V"/> <input type="button" value="±10 V"/> <input type="button" value="0-5 mA"/> <input type="button" value="0-20 mA"/> <input type="button" value="4-20 mA"/> <input type="button" value="T.4-20"/> <input type="button" value="ER.4-20"/> <input type="button" value="E.T.4-20"/>	Selection of range for analogue output	
	A.O. MIN.	>	<input type="button" value="-99999...0...99999"/>	Assigning the value of the input to the lower end of the range of AO	<input type="button" value="T.4-20"/> with error indication (< 3.2 mA)
	A.O. MAX.	>	<input type="button" value="-99999...100...99999"/>	Assigning the value of the input to the upper end of the range of AO	

## Service

Setting of password	PASSW.	>	<input type="button" value="0...9999"/>	Password to connect the device to PC. If it is set to "0", access is not blocked
Delayed Start	DLY.STR.	>	<input type="button" value="0...99"/>	Setting the time [sec] - when the measurement is not performed after powering the device on
Save user settings	SAV.SET.	>	<input type="button" value="YES"/>	Saves the current device settings
Load user settings	LOA.SET.	>	<input type="button" value="YES"/>	Loads the user settings into the device
Factory reset	FACT.ST.	>	<input type="button" value="YES"/>	Loads the original factory settings, restores the initial settings (BLUE TEXTS)
Erase user calibration	CLR.CAL.	>	<input type="button" value="YES"/>	Clears user calibration, restores factory calibrations (after user calibration by script via OM Link SW had been performed)
Key lock	KEY.LCK.	>	<input type="button" value="ON"/> <input type="button" value="OFF"/>	Disables the push button(s) on the front panel of the device
Error selection for signalling	SIG.ERR.	>	<input type="button" value="ERR 1"/> <input type="button" value="ERR 3"/> <input type="button" value="ERR 10"/> <input type="button" value="ERR 20"/> ...	Errors that will be signalled on the selected output
Simulation of input signal	SIM.MIN.	>	<input type="button" value="MIN"/> <input type="button" value="-99999...0...99999"/>	Setting of the start of the range for simulation
	SIM.MAX.	>	<input type="button" value="MAX"/> <input type="button" value="-99999...100...99999"/>	Setting of the end of the range for simulation
	STEP	>	<input type="button" value="-99999...1...999999"/>	Setting of increment/step value
	TIME	>	<input type="button" value="0...100...999.9"/>	Setting the increment/step duration time [sec]
	START	>	<input type="button" value="STOP"/> <input type="button" value="YES"/>	Start of simulation
	STOP	>	<input type="button" value="START"/> <input type="button" value="YES"/>	Stop of simulation

## Error messages

Error	Error description	Solution
ERR 1	Input range exceeded by ±10% or more.	Change input signal value or input setting (range).
ERR 3	Potentiometer wire broken.	Check sensor cable and connection.
ERR 10	Output current loop broken.	Check cable and current loop connection.
ERR 20	Math function error.	Change math function settings.
ERR 21	Linearization table error.	Change/complete the settings of the linearization table.
ERR 30	Powered only by USB, analog circuits inactive.	Connect power supply to the device (clamp 1,2).
ERR 34	Default configuration not successfully set.	Repeat device configuration. If message is shown repeatedly, send the device for repair.
ERR 35	Factory default calibration not successfully set.	When this error occurs, send the device for re-calibration or upload factory calibration data.
ERR 36	Default user calibration not successfully set.	Repeat the user calibration. If message is shown repeatedly, send the device for repair.
ERR 50	Serious device error - damaged EEPROM. The device operates in an emergency mode, i.e. settings cannot be changed. Measurement error can be up to 5%	Send the device for repair.


Errors ERR 34-50 are displayed permanently, until they are corrected.



The USB connector is galvanically connected to the input! USB-to-USB Isolator must be used when input signal is connected to the device.

**DANGER OF COMPUTER DAMAGE**

## 5 Instrument dimensions and installation



## 6 Technical data

### INPUT

No. of inputs	1
Setting	24-bit $\Delta\Sigma$ ADC with PGA The range is selectable either by DIP switch or by OM Link free SW from PC
DU Power	2.5 VDC/5 mA, potentiometer resistance > 500 $\Omega$

### EXTERNAL INPUT

No. of inputs	2, on contact																		
Function	<table border="0"> <tr> <td>OFF</td> <td>No function assigned</td> </tr> <tr> <td>TARE</td> <td>Activation of Tare</td> </tr> <tr> <td>CL.TAR.</td> <td>Reset of Tare</td> </tr> <tr> <td>HOLD</td> <td>Measurement paused</td> </tr> <tr> <td>SAMPLE</td> <td>Take a one-off measurement</td> </tr> <tr> <td>HLD.MIN</td> <td>Value of minimum *</td> </tr> <tr> <td>HLD.MAX</td> <td>Value of maximum *</td> </tr> <tr> <td>HLD.M-M</td> <td>Value of MAX-MIN*</td> </tr> <tr> <td>KEY.LCK.</td> <td>Device buttons blocked</td> </tr> </table>	OFF	No function assigned	TARE	Activation of Tare	CL.TAR.	Reset of Tare	HOLD	Measurement paused	SAMPLE	Take a one-off measurement	HLD.MIN	Value of minimum *	HLD.MAX	Value of maximum *	HLD.M-M	Value of MAX-MIN*	KEY.LCK.	Device buttons blocked
OFF	No function assigned																		
TARE	Activation of Tare																		
CL.TAR.	Reset of Tare																		
HOLD	Measurement paused																		
SAMPLE	Take a one-off measurement																		
HLD.MIN	Value of minimum *																		
HLD.MAX	Value of maximum *																		
HLD.M-M	Value of MAX-MIN*																		
KEY.LCK.	Device buttons blocked																		

\*The value is calculated from the period starting with the previous external input activation.

### INSTRUMENT SPECIFICATION

TC	15 ppm/ $^{\circ}$ C
Accuracy	$\pm 0.01\%$ of FS
Rate	100...7 200 measurements/s speed of 400 meas./s is with FFT signal filtering
Latency	< 580 $\mu$ s
Overload	10x (t < 30 ms), 2x
Functions	Teach-in, Tare, Math. functions, Simulation
Digital filters	exponential / floating / arithmetic average, rounding
Math functions	polynomial / inverse polynomial / logarithm / exponential / power / root
Linearization	linear interpolation in 100 points (only via OM Link)
OM Link	company communication interface for operation, setting and update of instruments. (microUSB)
Watch-dog	reset after 500 ms
Calibration	at 25 $^{\circ}$ C and 40 % r.h.

### ANALOG OUTPUT

No. of outputs	1
Type	isolated, adjustable with 16-bit DAC, output type and range is selectable
TC	15 ppm/ $^{\circ}$ C
Non-linearity	0.024 % of FS
Accuracy	$\pm 0.02\%$ of FS $\pm 0.03\%$ of FS $\pm 0.05\%$ of FS
Rate	response to change of value < 160 $\mu$ s
Output signals	0...2.5/10 V, $\pm 10$ V, resistive load $\geq 1$ k $\Omega$ 0...5/20 mA/4...20 mA, comp. < 600 $\Omega$ /12 V Indication of broken current loop Indication of error message (output < 3.2 mA)

### POWER SUPPLY

Power	10...30 VDC/24 VAC, $\pm 10\%$ , 2.5 VA, PF $\geq 0.4$ , $I_{rip}$ < 40 A/1 ms, isolated Fuse inside (1500mA)
-------	---

### MECHANICAL PROPERTIES

Material	PA66, incombustible UL 94 V-0, green
Dimensions	25 x 79 x 90.5 mm (w x h x d)
Installation	to DIN rail 35 mm wide

### OPERATING CONDITIONS

Connection	connector terminal blocks, section < 1.5 mm <sup>2</sup>
Stabilization period	within 5 minutes after switch-on
Working temp.	-20 $^{\circ}$ ...60 $^{\circ}$ C
Storage temp.	-20 $^{\circ}$ ...85 $^{\circ}$ C
Working humidity	< 95 % r.h., non condensing
Protection	IP20
Construction	safety class I
El. safety	EN 61010-1, A2
Dielectric strength	2.5 kVAC for 1 min. between power supply and signal input 2.5 kVAC for 1 min. between signal input and outputs
Insulation resistance*	for pollution degree II, measurement cat. III power supply > 300 V (PI), 255 V (DI) Input/outputs > 300 V (PI)
EMC	EN 61326-1 (Industrial area)
RoHS	EN IEC 63000 : 2018
Seismic qualification	IEC/IEEE 60980-344 Edition 1.0, 2020, par. 6, 9
Mechanical resistance	EN 60068-2-6 ed. 2:2008

\* PI - Primary insulation, DI - Double insulation



Measuring instruments of the OMX380DU series conform to the European regulation 2014/30/EU, 2014/35/EU and 2011/65/EU, 2015/863/EU.

This product must be installed, connected and used in compliance with prevailing standards and/or installation regulations. As standards, specifications and designs develop from time to time, always ask for confirmation of the information given in this publication.